



First Floor  
64 Grant Avenue  
Cnr Algernon Street  
Norwood 2192 Johannesburg  
Gauteng South Africa

PO Box 1541 Highlands North 2037  
Tel: 27 11 728 0039  
Fax: 27 11 483 0084  
web: [www.strivesoft.com](http://www.strivesoft.com)  
e-mail: [info@strivesoft.com](mailto:info@strivesoft.com)

Congratulations on purchasing The Strive Pen. You have made a great choice.

## Installation Instructions

1. Do not plug the device into your computer until the software tell you to:

Using the small CD labelled Pen Grand Master, install the whiteboard driver software by running **\PGM 100 setup files\PGM100\_Cht\_Eng\_Kor\_32 bit \_050210.exe (for 32bit Windows) or \PGM 100 setup files\PGM100\_Cht\_Eng\_Kor\_64 bit setup file.exe (for 64bit Windows)**. NB: You must have administrator privileges for successful installation. Follow the on screen instructions.

2. Put the whiteboard receiver close to the projector
3. Run the whiteboard software by clicking on Start / All Programs / PenGrandMaster100 / PGM100
4. Move the whiteboard receiver until all the dots are in the block, not jumping around and are blue or red. Then press F5 on the whiteboard pen.
5. You should now be able to use the whiteboard pen.
6. Remember to turn off the whiteboard pen to save batteries.